

safariPlast



Body Cladding Assembly Guide



Required 2 people for assembly



Cleaning liquid or M600 thinner, fiber gland



Adhesion Promoter



Hot air gun



Assembly time 30 minutes



Image 1.1

- Image 1.1 Pay attention the surface to be assembled is clean and dry
- Clean the the surface to be assembled via cleaning thinner (M600) or cleaning liquid



Image 2.1

- Image 2.1 The tape protection of the part to be assembled must be marked and indicated from the reference points before it is taken out.
- Match product to door as equal at point marked by arrow
- This process is used for all products.



Image 3.1

- Image 3.1 Apply the adhesion promoter in direction of arrows matching tape on the product and without moving outside the previously referenced lines



Image 4.1



Image 4.2



Image 4.3

- Image 4.1 Take out the protection tape .
- Image 4.2 Heat the tape surfaces via a hot air gun if the weather is below 17 °C, also heat the vehicle surface too.
- Image 4.3 Carefully paste product to be assembled to the surface referenced
- This process is used for all products.



Image 5.1

- Image 5.1 Apply pressure taped surfaces of product to be assembled with wet fiber gland for pasting on better
- This process is used for all products.



Image 6.1

- Image 6.1 The product is ready to use